



SJE Oil Spotter™ System installation instructions

Designed to control one 120 VAC single phase pump using a receptacle for easy pump connection in indoor pump applications. No wiring needed.

The SJE Oil Spotter™ control and alarm system provides a convenient location for all wiring required for an indoor simplex pump application. The SJE Oil Spotter™ employs a receptacle to accept one 120 VAC pump plug.

In normal operation the pump will turn on and off with the water level activating the probes (5" pumping range). If water gets high enough to activate the High Water probe, a red indicator will illuminate and activate auxiliary contacts. If the oil level reaches the High Oil float, a red indicator will illuminate and activate the auxiliary contacts.

SJE OIL SPOTTER™ FEATURES

- NEMA 1 rated for indoor use.
- Factory-installed 10ft power cord.
- SJE Oil Spotter™ Panel with LED indicators for:
 - High Water Indicator (red)
 - High Oil Indicator (red)
 - Pump Run Indicator (green)
 - Power Indicator (green)
- Factory-installed Oil Water Switch includes:
 - High Oil Float
 - High Water Probe
 - Start Probe
 - Stop Probe
 - Reference Probe
- Entire system is UL and cUL Listed to meet and/or exceed industry safety standards.
- Three-year limited warranty.

PREVENTATIVE MAINTENANCE

- Periodically inspect the product. Check that the cable has not been damaged so as to impair the performance of the product. Replace the product immediately if any damage is found or suspected.
- Use only SJE-Rhombus® replacement parts.

SJE-RHOMBUS® THREE-YEAR LIMITED WARRANTY

SJE-RHOMBUS® warrants to the original consumer that this product shall be free of manufacturing defects for three years after the date of consumer purchase. During that time period and subject to the conditions set forth below, **SJE-RHOMBUS®** will repair or replace, for the original consumer, any component which proves to be defective due to defective materials or workmanship of **SJE-RHOMBUS®**.

ELECTRICAL WIRING AND SERVICING OF THIS PRODUCT MUST BE PERFORMED BY A LICENSED ELECTRICIAN.

THIS WARRANTY DOES NOT APPLY: (A) to damage due to lightning or conditions beyond the control of **SJE-RHOMBUS®**; (B) to defects or malfunctions resulting from failure to properly install, operate or maintain the unit in accordance with printed instructions provided; (C) to failures resulting from abuse, misuse, accident, or negligence; (D) to units which are not installed in accordance with applicable local codes, ordinances, or accepted trade practices, and (E) to units repaired and/or modified without prior authorization from **SJE-RHOMBUS®**.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

TO OBTAIN WARRANTY SERVICE: The consumer shall assume all responsibility and expense for removal, reinstallation, and freight. Any item to be repaired or replaced under this warranty must be returned to **SJE-RHOMBUS®**, or such place as designated by **SJE-RHOMBUS®**.

ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS ARE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. SJE-RHOMBUS® SHALL NOT, IN ANY MANNER, BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES AS A RESULT OF A BREACH OF THIS WRITTEN WARRANTY OR ANY IMPLIED WARRANTY.

⚠ WARNING**ELECTRICAL SHOCK HAZARD**

Disconnect power before installing or servicing this product. A qualified service person must install and service this product according to applicable electrical and plumbing codes.

⚠ WARNING**EXPLOSION OR FIRE HAZARD**


Do not use this product with flammable liquids. Do not install in hazardous locations as defined by National Electrical Code, ANSI/NFPA 70.

Failure to follow these precautions could result in serious injury or death. Replace product immediately if switch cable becomes damaged or severed. Keep these instructions with warranty after installation. This product must be installed in accordance with National Electric Code, ANSI/NFPA 70 so as to prevent moisture from entering or accumulating within boxes, conduit bodies, fittings, float housing, or cable.

For detailed specifications on this product, or for the complete line of SJE-Rhombus® panel, alarm, and switch products, visit our web site at www.sjerrhombus.com.

INSTALLING THE SJE OIL SPOTTER™ SYSTEM CONTROL PANEL


1. Determine desired location to mount the SJE Oil Spotter™ control panel (**Figure A**).
2. Attach the mounting flanges to the control panel enclosure. Mount panel at the desired location making sure the mounting location of the control panel is within 10 feet of electrical receptacle and the Oil Water Switch mounting location.
3. Plug power cord into electrical receptacle only when ready for testing. Verify the green "power" light illuminates.
4. Make sure to test SJE Oil Spotter™ System (see page 4).

Figure A

INSTALLING THE OIL WATER SWITCH


1. Determine the proper position for the oil water switch (**Figure B**).
2. Position the Oil Water Switch at the appropriate location on the pipe and secure the switch as shown(**Figure B**).
3. Tighten all hose clamps using a screw driver. Over-tightening may result in damage to the plastic parts.
Note: All hose clamp components are made of 18-8 stainless steel material. See your SJE-Rhombus® supplier for replacement parts.

Figure B



If using auxiliary contacts, connect wire to terminal block as shown in **Figure C**.

Figure C



Note: Tank Alert® alarm(s) are needed for the above applications.

TESTING THE SJE OIL SPOTTER™ SYSTEM

Remove oil from pit prior to testing.

DISPOSE OF OIL IN ACCORDANCE WITH STATE AND LOCAL CODES

1. Verify the green "power on" indicator on panel is illuminated.
2. Unplug pump power from receptacle on panel, then fill sump pit with water until Red "High Oil" indicator on panel illuminates. If using auxiliary contacts, they will be in alarm condition.
3. Plug pump power into panel. Pump will run until water drops below "Stop" probe. If using auxiliary contacts, they will be in alarm condition.

Note: Test SJE Oil Spotter™ System every two weeks.

NOTES:



22650 County Highway 6 ■ P.O. Box 1708 ■ Detroit Lakes, Minnesota 56502 USA
1-888-DIAL-SJE (1-888-342-5753) ■ Phone: 218-847-1317 ■ Fax: 218-847-4617 ■ E-mail: sje@sjerhombus.com